


Encompass® 6 Multiprotocol Reader Quick Reference Card


1 ANTENNA MULTIPLEXING/CHECK TAG PORT
 Recommended Data Cable: 9-pin ribbon cable
 Recommended Check Tag Antenna Cable:
 50-ohm coaxial cable (≤ 3 dB loss in cable)
 Encompass 6 jack is DB9 socket connector



2 TDM/COM1 PORT
 Recommended COM1 Port Data Cable: 20 AWG cable
 Recommended TDM Cable: Belden 89182 (outdoor-rated)
 Recommended TDM Cable: Belden 8132 (not outdoor-rated)
 Mating connector (TransCore P/N 33357-01)
 Installed on Encompass 6 jack



3 COM2 PORT
 Recommended Cable: 20 AWG cable
 Encompass 6 jack is DB9 plug connector




4 ANTENNA PORT
 Recommended Cable: 50-ohm coaxial cable
 AA3152 Universal Toll Antenna recommended
NOTE: Use the RF MONO port for single-antenna installation
CAUTION: Tighten antenna SMA connector to
 10 in/lb only. Do not cross-thread the
 connector when tightening

5 ETHERNET PORT
 Recommended Data Cable: Belden 7929A Paired
 Category 5e (outdoor-rated)
 Maximum Length: 330 feet (100 m)
 RJ-45 jack

11 FAULT/OPERATIONAL LEDs
 (see other side
 for descriptions)

10 POWER LEDs
 (see other side
 for descriptions)




6 DIAGNOSTIC TEST PORT
 Used for factory diagnostic testing only

7 EXTERNAL DIGITAL INPUT/OUTPUT PORT
 Data Cable: 20 AWG wire
 Mating Connector (TransCore P/N 33357-01)
 Installed on Encompass 6 jack



8 GPS TIMING PORT
 Data Cable: 20 AWG wire
 Antenna Cable: 50-ohm coaxial cable
 ≤ 12 dB @1.575 GHz



9 POWER REQUIREMENTS
 Input Supply Voltages
 19V DC to 30V DC or
 19V AC to 27V AC RMS @47 to 63 Hz

Input Power
 DC or AC: 40 watts maximum

In-rush Current
 8 amps (A) maximum, ≤ 25 milliseconds (ms)

Transformer: (TransCore P/N 76-6000-001)
 110V AC or 220V AC input, 24V AC output

Power Cable: 12-22 AWG cable
 Mating Connector (TransCore P/N 33356-01)
 (1 each) and P/N 33358-01 (2 each) installed
 on Encompass 6 jack

CAUTION: Wire gauge depends on wire resistance
 versus overall wire length with respect to the
 Encompass 6 reader's specified voltage range
 and power rating.

(See other side for AC power supply wiring.)



CAUTION:
 Loosen mounting screws before
 removing plug.

Encompass® 6 Multiprotocol Reader Quick Reference Card

Choosing a Power Supply


Consider these factors when choosing a power supply:

1. Input voltage: 19V to 30V DC or 19V to 27V AC RMS @47 to 63 Hz, in-rush current: 8A maximum, ≤25 ms. (See Power Requirements on other side for additional Encompass 6 requirements.)
2. Operating temperature of power supply and power cable
3. Power cable gauge and length. TransCore recommends using 12 to 22 AWG cable to Encompass 6.

Power Supply Accessory Kit

Part Number	Description
76-6000-001	110V AC or 220V AC to 24V AC transformer

CAUTION: Wire gauge depends on wire resistance versus overall wire length with respect to the Encompass 6 reader's specified voltage range and power rating.



AC Power Wiring Diagram

(Refer to Encompass Reader System Guide for DC Power Wiring Diagram.)

Power LEDs (item 10 from other side)

POWER LED	INDICATION
PWR	19V to 30V DC or 19V to 27V AC supplied
+5	+5 volt power supply functioning
+10.5	+10.5 volt power supply functioning
+5.5	+5.5 volt power supply functioning
+7	+7 volt power supply functioning
-5.5	-5.5 volt power supply functioning

Equipment Licensing

The user is required to obtain a Part 90 site license from the FCC to operate the unit in the United States. Access the FCC Web site at www.fcc.gov for more information.

FCC ID: F1HMPI6000 A

Users in all countries should check with the appropriate local authorities for licensing requirements.

Fault/Operational LEDs (item 11 from other side)

THREE FAULT INDICATION LEDs*			
ERR3	ERR2	ERR1	FAILURE MODE
●	●	●	Microprocessor resetting
●	●	○	Power supply failure
●	○	●	Transceiver failure
●	○	○	TDM/GPS failure
○	●	●	No communication with lane controller/host
○	●	○	Other failure
○	○	●	Data in buffer
○	○	○	No failure
OPERATIONAL LEDs		INDICATION	
RDR	●	Encompass 6 communicating with host	
LC	●	Host communicating with Encompass 6	
TIF	●	Encompass 6 transacting with tag. LED lit when Encompass 6 receives correctly decoded tag message including correct cyclic redundancy check for message. The LED is lit for 250 ms following a tag transaction.	
UL	●	RF uplink signal on	
DL	●	RF downlink signal on	

Start Up

Perform the following startup procedures:

1. Connect antenna to Encompass 6 at RF MONO port.
2. Connect COM1 or Ethernet cable depending on communication configuration.
3. Connect other options as needed.
4. Connect AC or DC power to Encompass 6. Power LEDs should light.
5. Encompass 6 starts up in Mode 0 (Stop).
6. Set commands as required for your configuration.
7. Send Set Mode command to Encompass 6 from host.

Troubleshooting

Perform these troubleshooting procedures:

1. Make sure all connectors are secure.
2. Make sure Encompass 6 is powered up by checking Power LEDs.
3. Make sure Encompass 6 is communicating with host.

If system does not respond to troubleshooting, contact TransCore Customer Service at transcore.com/rfidsupport.

*If multiple faults occur, the highest priority fault displays. For example, if the microprocessor is resetting (highest priority) and the power supply fails (second highest priority), the microprocessor fault indication displays until it is cleared.

For support, contact TransCore at transcore.com/rfidsupport

